

Index to Contents.

(See Index also to new matter added to Fourth Revised Edition—including High Speed Steels.)

Action of charcoal on steel	36
Cyanide	10
Aging of gauges	196
Steel	241
Agitated baths	90-91-93
Air annealing	71
Air blast for cooling	280
Should not strike steel	35-63
Air blasts cause cracks	299-302
Air hardening steel	278
Annealing	281
Air jet in case hardening	233
Alloy steels	277
Anneal at uniform heat	84
Annealing	271
After blocking out	301
Between boards	73
Methods of	71
Roughing out	78
Annealing in ashes	72
Cold water	73
Crucibles	97
Furnace—danger of	74-75
Gas furnace	74-75
Iron boxes	75-76-77
Lime	72
Machinery steel	81
Object of	71
Self-hardening steel	281
Sheet steel	270
Wrong way	81
Arbors and mandrels	219-220

Arbors for saws	286
Arbors—taper	187
Appliances for case hardening	242
Ashes for annealing	72
Attempting the impossible	127
Augers	287
Axes	287
Axles—case hardening of	246
Balls—case hardening of	242
Barrel for hardening bath	256-257
Barrels for guns	287
Baskets for hardening	111
Bath for case hardening small pieces	229
Cooling mandrels, etc.	191
Grooved rolls	194
Hardening taps	157-158-160
Springs	86
Toughening	87
Bath of oil for springs	263-264
Baths for case hardening	254
Baths for hardening	
Brine	86-89
Citric acid	87
Hardening	85-86-87-96
Hardening dies	133-135-136
Heated	66-92
Heat for best work	156
Lead	96
Mercury	85
Oil	86
Oil and water	88
Poisonous baths	87
Saltpeter	87
Springs	260-261
Sulphuric acid bath	87
Water	86
With liquid in motion	90-91-93
Bench vises—jaws for	291
Bessemer steel—case hardening of	238
Hardening	111
Not good for tools	275

Best steel for mandrels or arbors.....	189
Punches.....	142
Bevel gears for bicycles.....	235
Bicycle axles.....	246
Chains.....	239
Cones—hardening.....	202
Crank testing.....	82
Parts—case hardening.....	234
Blacksmiths' chisels.....	287-288
Forge for hardening dies.....	129-130
Forge—heating in.....	35
Hammer.....	290
Hardies.....	291
Punches.....	294
Blades of knives.....	290
Blame—shifting of.....	80
Blaming the hardener.....	303
Blanking dies.....	214
Blanking press dies.....	289
Blanking work punches.....	294
Blister steel.....	276
Blocking out work for annealing.....	78
Blow pipe and candle for tempering.....	162
Blow pipe and spirit lamp.....	44-45
Boiling water for springs.....	265
Bolt dies.....	289
Bone.....	223
Black for case hardening.....	223
Cast iron in.....	316
Charred.....	314-315
Expended.....	316
Packing steel in.....	316
Preserving.....	316
Should never be used in pack hardening.....	250
Borax—substitute for.....	313
Boxes for heating dies.....	132
Pack hardening.....	206-209
Box for case hardening.....	227-239
Hardening springs.....	263
Heating swaging dies.....	224
Brine bath.....	86
Brittleness.....	56

Brittleness—due to phosphorus.....	83
In wood-working tools.....	200
Bunsen burner.....	44-45
Burns from cyanide—caution.....	110
Burnt steel—restoring.....	298
Bursting from internal strains.....	65
Cams of low grade steel.....	241
Candle and blow pipe for tempering.....	162
Carbonaceous paste.....	46
Carbon and quality.....	22
Best for various tools.....	284
Necessary for good results.....	29
Penetrates iron.....	275
Percentage of.....	15-20-21-29-33
Surface.....	63
Careful hammering.....	69
Carelessness.....	303
Careless workmen.....	17
Carriage springs.....	296
Case hardening.....	225
Baths.....	254
Bicycle parts.....	235
Furnaces.....	253-254
Gas pipe.....	226
Imitation of.....	111
Machine nuts.....	251
Many small pieces.....	229
Portion of piece.....	248
To leave soft places.....	249-250
Cast iron bad for steel.....	206
In annealing.....	76-81
Cast steel.....	286
Catch pan in baths.....	229-256
Causes of trouble.....	297
Cautions about lead bath.....	100
Cemented steel.....	275
Centering steel.....	23-24
Centers for lathes.....	287
Of mandrels or arbors should be hard.....	191
Chain blocks.....	239
Chain studs.....	247

Charcoal	232
Action of on steel	36
Annealing	75-76-77
Prevents dross	101
Charred bone for colors	314
Leather for annealing	85
Leather for heating dies	132
Leather—making	313
Leather toughens steel	239
Charring the bone	315
Cheapening cost of production	8
Cheap steel	31
Chilled iron—steel for	281-282
Tools for	293
Chisels for cutting steel	287
Chisels for wood	287
Chisel temper	27
Choosing steel	28
Chuck jaws	291
Cigars—effect on steel	87
Circulation of water necessary	256-257
Citric acid bath	87
Clay for filling corners	176
Clean fires	302
Clock springs—hardening	260
Coals not always good	63
Coke for high carbon steel	37
Cold air blast cracks steel	35-63
Baths not usually advisable	114-300
Bending of springs	269
Causes cracks	299
Chisels	287-288
Water annealing	73
Water bad for springs	259
Work	287-288
Collars to prevent case hardening	251
Color blindness	11
Coloring gun frames	109
Colors denote temper	117-123
For springs	269
In case hardening	233
Obtained with cyanide	108

Colors on case hardened work	258
On malleable iron	111
Reason for	124-125
Visible	117
Cooling case hardened work	234
Deep hole in die	94
Device for gauges	196
Dies for screw cutting	151
Flat plates	179
Grooved rolls	193
Gun springs	182
Half round reamers	163
In air blast	280
In bath	14
In small bath	94
Jaws of hardening device	181
Milling cutters	166
Pieces with holes near edge	199
Plate mounted on springs	181
Shank mill	94
Springs	262-263-264
The oil bath	263-264
Thin pieces	245
With dirty water	95
Commercial bars vs. hammering	70
Common error	279
Compounds for hardening	88
Cones for bicycles—hardening	202
Considerations in hardening	127
Continued heating	84
Continuous or agitated baths	90-91-93
Contraction and expansion	12-14
Converted steel	275
Correcting wrong annealing	82
Cost of production	8
Testing steel	33
Counterbores	158-187-188
Countersinking too deeply	187
Covering paste	46
Cracking in lead bath	100
Liability of	271
Of hollow articles	175

Cracking of round pieces.....	62
Cracks.....	14-35-298-299
Cause of.....	305
Prevention of.....	203-204
Where they occur.....	100
Crank axles—hardening.....	235-246
Critical temperature.....	13
Crucible cast steel.....	276
Steel.....	286
Crucibles—annealing.....	97
Should always be emptied.....	101
Used for lead baths.....	97
Crushing grain in hammering.....	69-70
Cutters for milling machine.....	288
Glass.....	288
Pipe cutting.....	288
Cutting pliers.....	291
Point of tools.....	7
Tools—hardening.....	86-87
Tools of machine steel.....	241-243-272-274
Cyanide—action of.....	106
Bath best for cutting tools.....	105
Bath for watch springs.....	267
Coloring with.....	108
Hardening furnace.....	106
Hardens surface.....	107
Heated in open forge.....	50
Heating bath—advantage of.....	46-108
Of potassium a poison.....	107
Of potassium bath.....	105
Of potassium for case hardening.....	227
Of potassium furnace.....	51-52
Should be chemically pure.....	106
Solution prevents lead sticking.....	98-103
Dampers.....	39-40
Danger from small fire.....	190
Cracking removed.....	138-139
In steel welds.....	311
Of cast iron in annealing.....	76-81
Overheating in annealing.....	74-75-83
Decarbonized surface.....	23-28-35-45-61-64

Deep case hardening.....	232
Deep fire best.....	35
Defects in steel—lack of.....	302
Degrees of hardness.....	284
Depth of hardening.....	89
Detecting time of cracking.....	100
Device for cooling thin plates.....	179-180
Die or punch hardest?.....	140
Dies—baths for hardening.....	133-136
Blanking press.....	289
Boxes for heating.....	132-224
Cracking from internal strains.....	154
Drawing.....	290
Drawing temper of.....	139
Drop forging.....	290
For cartridges and other work.....	197
Forming.....	144
For punching.....	241
Furnace for.....	130-131-137
Heating in charred leather.....	132
Hardening.....	149-204-215-221
Heating.....	40
Heating box for.....	145
Hobs for.....	291
Method of cooling.....	151
Methods of hardening.....	129
“Spring”.....	153
Starting scale before hardening.....	134
Tempering.....	153
Tongs or grappling hooks.....	135-136
To prevent cracking.....	138-139
Punch press work.....	138-143-249
Ring.....	144
Ring—furnace for.....	145
Screw cutting.....	289
Swaging.....	289
Threading bolts.....	289
Difference in steel.....	16
Different results in case hardening.....	237
Steels.....	26
Difficult pieces to harden.....	217-218
Dipping thin pieces.....	245

Dirty water for cooling.....	95
Disc cracked in grinding.....	306
Dont's.....	280-301
Doubts about steel.....	274
Drawing dies.....	290
Forming dies.....	144
Milling cutters.....	167-168
Punches.....	142-143
Ring dies.....	147-148
Slitting saws.....	183
Springs.....	265-266
Temper.....	56-116
Temper of dies.....	139
Temper of T slot cutters.....	174
Draw knives.....	228
Drill rod not good for punches.....	142
Drills for rock.....	290
Twist.....	290-309
Drop forging dies.....	290
Dull cutters spring work.....	303
Eccentric centering.....	24
Holes in articles.....	198
Economy in heating.....	45
Of inspection.....	33
Effect of continued heating.....	84
Heat on hammered steel.....	69
Oil on temper color.....	125
Slight changes in heat.....	123-124
Emergency annealing.....	74
Emery wheel—use proper.....	307
Equalizing heat of lead bath.....	106
Error—common.....	279
Even heating by lead bath.....	92
Exact tempering by thermometer.....	123
Examples of hardening.....	127
Expansion and contraction.....	12
Expended bone for Bessemer steel.....	238
In annealing.....	83
Experience.....	16
Experiment in partial hardening.....	248
Extravagant economy.....	24
Extreme hardness.....	285

Falling heat.....	62
Files.....	290
Method of hardening.....	99
Filletts in counterbores.....	187
T slot cutters.....	172-173
Filling corners with graphite or clay.....	176
Fire-clay to prevent hardening.....	249-250
Fire cracks.....	299
Fixture for handling ring dies.....	147
Fixtures for use in hardening.....	201-202
Flashing springs.....	265
Flat plates—methods of cooling.....	179
Springs.....	270
Flexibility of hardened steel.....	66
Fluxes.....	310-311-313
Forging.....	68
And tempering at once.....	71
Dies (drop forging).....	290
Improper.....	300
Self-hardening steels.....	279-280
Troubles.....	68
Forming dies.....	144
Tools.....	221
Fuels.....	36-37-38
For hardening baths.....	96
Fumes from cyanide furnace.....	52-53
Lead baths.....	47-51
Furnace for case hardening.....	242
Case hardening.....	253-254
Dies.....	130-131-137
Heating baths.....	47-49-51-52
Heating springs.....	262
Heating taps.....	159
Heavy dies.....	136-137
Lead heating.....	96
Pack hardening.....	210
Ring dies.....	145
Furnaces—location of.....	54
Gas as fuel.....	37
Blast for heating.....	42-43-44-45
Furnace for dies.....	137

Gas pipe for case hardening.....	228
Gauges—aging of.....	196
Crack from grinding.....	305
Hardening ring.....	195-196
Packing for hardening.....	240
Snap and ring.....	215-216-218
Gear for chainless bicycles.....	235
Genesis of pack hardening.....	203
German steel.....	276
Glass bath for hair springs.....	267
Cutters.....	288
Hardening bath for watch springs.....	54
Heating baths.....	46
Government method of hardening files.....	98-99
Grain of tool steel.....	55-56-57-61
Granulated raw bone.....	243
Graphite for filling corners.....	176
Grinding cracks tools.....	305-306
Taps to show color.....	161
Tools right.....	307
Gripping jaws.....	292
Grooved rolls—hardening.....	192
Gun barrels.....	287
Gun frames—coloring.....	109
Hardening.....	252
Springs—cooling.....	182
Hair springs.....	267
Half round reamers.....	162-163
Hammer—blacksmiths'.....	290
Machinists'.....	291
Refining.....	69-70
Hammered steel.....	69
Handle-bar binders.....	235
Handling heavy dies.....	135-136
Maximum amount of work.....	104
Ring dies.....	146
Harden at lowest heat.....	126
Hardened work—straightening.....	115
Hardening.....	22
Arbors.....	189
A screw driver.....	184

Hardening baths.....	85-86-87-96-105
Bessemer steel.....	111
Between plates.....	178
Bicycle parts.....	235
Compounds.....	88
Cutting tools.....	86
Depth of.....	89
Dies.....	129
Dies without "twist".....	150
Eccentric pieces.....	198
Files.....	98-99
Fixtures.....	201-202
Grooved rolls.....	192
Half round reamers.....	163
High carbon steel.....	285
Holes.....	90-93
Hollow mills.....	175
Hot water.....	113
In baskets.....	111
Large pieces.....	35
Lead.....	96
Locally.....	252
Long tools.....	30-104-154-155-258
Machine for thin articles.....	180
Machinery steel.....	110-111-225
Malleable iron.....	110
Mandrels, arbors, etc.....	189
Milling cutters.....	164-165
Places.....	248
Ring dies.....	144-145-147
Saws.....	178
Screw cutting dies.....	149
Shank mills.....	169-170
Small tools—mixture for.....	98
Springs.....	259-260-261-262-263-264-265
Steel.....	112
Taps and dies.....	53-156-160-202
Temperature of different steels.....	59
The punch.....	141
Thin pieces.....	178-244
Walls of holes.....	195
Watch springs.....	54

Hardening wood-working tools	200-201
Hardies for blacksmiths	291
Hard metals—steel for	277
Hardness—degrees of	284
Due to cyanide bath	51
Extreme	285
Heat depends on carbon	55
For welding	310
High	297
Necessary to draw temper	117
Of lead bath—care about	102
Rapid	298
Refining	13-56
Should be low as possible	13
Slow	299
Slowly for tempering	140-125
"Soaking"	299
Strength depends on	107
Uneven	297
Work—timing	231
Heated baths	66-92
Advantages of	156
Heath	277
Heating articles of irregular shape	67
At right speed	60-61
Box for ring dies	145
Cyanide in an open forge	52
Cyanide of potassium	46
Dies	40
Dies in boxes	132
Dies—proper method	133
For hardening with lead bath	96-100
Gas blast	42-43-44-45
Glass	46
Grooved rolls	192
In a forge	35
Lead	46-49
Tin	46
Tubes in open fire	63
Large work	45
Long tools in lead bath	104
Machine for slender punches	143

Heating mandrels	186-189
Screw dies in boxes	152
Slender punches	143
Small work in tubes	41-42
Steel—methods of	34
The baths	92
To avoid strains	113
Tool steel	55
Uniformly	14-60-62
Various substances	46
Water for hardening tools	104-113
Wood-working tools	201
Work in cyanide bath	105
Heavy and light portions	62
Blows when hot	69
Cuts	65
Punches	142
Springs	265
High carbon steel	30-278-283
Duty steels	277
For punches	142
Heats	297
Heats open grain	69-70
Speed steel	277
Hobs for dies	29
Holes—hardening	90-93
Hardening out of round	195
In dies—cooling of	93
In shank mills	171
Near edge	198
Stopped with clay	138
Hollow articles—to prevent cracking	175
Danger of steam forming in	175
Mills	174-175
Home-made furnace for dies	131
Furnaces	39-40-47-49-53
Gas blast oven	44
Lead heating apparatus	49-50
Hot lead for hardening	96
Water bath for springs	265
Work—chisels for	287
How to case harden small quantities	226

How to pack harden	207
Huntsman, Benjamin	276
Hydrocarbonated bone	233
Identifying steel	33
Imitation case hardening	111
Importance of cutting point	7
Improper forging	300
Heating and hammering	70
Impure lead injures steel	97
Increase in production	10
Indifference of some hardeners	64
Inspection of steel—economy of	33
Internal strains	65-79
Strains in dies	154
Iron boxes for annealing	75-76-77
Irregular shaped work	62-67
Jaws for bench vises	291
Chucks	291
Cutting pliers	291
Gripping	292
Pipe machines	292
Screw threading dies	292
Wire pullers	292
Jarolinech	13-59
Kettle for tempering in oil	122
Key ways	307
Knife blades	292
Knives—draw knives	292
Knowing it all	16
Labeling steel	33
Lack of ability	129
Large baths	95
Fire best for hardening	190
Tanks best	139
Work—caution about	222
Lathe centers	287
Tools	292-309
Tools—tempering	120
Lead and crucibles	97
Bath for hardening	96

Lead bath sometimes unsatisfactory—why	97-102
Furnace—handling work in	104
Hardening furnace	47-48
Heating baths	46-49
Heating furnace	96
Should be pure	97
Sticking to work	98-102
Too hot—caution about	102
Leather—charring	313
Charred for annealing	85
For heating dies	132
Length of time to heat	231
Liability of cracking	271
Lighter blows when cooling	69
Lime for annealing	72
Local case hardening	249-250
Hardening	252
Location of furnaces	54
Locomotive springs	296
Long taps—best methods for	158
Tools—hardening	154-155
Loss due to poor hardening	9-10
Low carbon steel for tools	272-274
Heats best	13
Heats for tempering	124
Lowest heat best for hardening	126
Lubricating tools	309
Machine for hardening thin articles	180
Steel for tools	241-271-274
Taps	296
Machinery crucible steel	293
Case hardening	225
Hardening	111
Steel	19
Machinists' hammer	291
Makeshift oven	128
Making a screw-driver	184
Malleable iron—hardening	110-111
Mandrels	293
And arbors	219-220
Taper	186-189

Men who harden	15
Mercury bath	85
Metcalf on "refining heat"	56
Method of cooling gun springs	182
Cooling for hardening	89-90-91
Drawing temper	118
Heating steel	34
Milling cutters	55-204-212-213-288-307-309
Arbors	286
Drawing temper of	167
Hardening	164-165
Machine	286
Reamers or taps	304
Mixing of different grades	28
Mixture for color work	233
Hardening small tools	98
Hardening springs	260-261
Heating wood-working tools	201
Machine steel tools	240-243
Mould for casting lead	101
Mowers	293
Muffle furnace for heating taps	159
Furnaces	37-41
Mushet	277
Mysteries—absence of	25
Nature of steel	11-80
Neat's-foot oil	261
New charcoal best	36
Nickel-plating prevents case hardening	251
Non-crackers	11
Nuts—case hardening	251
Oil affects temper color	125
And water bath	88-167
Bath	86
For case hardened work	234
Hardening	211-212-214
Hardening thin articles	181
Kettle	122
Long tools	104
Removing strains	67-68

Oil for hardening springs	263-264
Tempering furnace	121
Toughens springs	259
Wood-working tools	200-201
Overheated steel—restoring	298
Overheating	13
In annealing	74-75-83
Oxidized steel	63
Pack hardening	203
Arbors and mandrels	219-220
A "teaser"	218
Bath of oil for	211-212
Bicycle parts	236
Blanking dies	214
Boxes for	206
Danger in cast iron	206
Depth of hardened surface	205
Dies and taps	215-221
Difficult pieces	217
Don't use bone	205
Forming tools	221
Furnace for	210
Gauges	215-216-218
Heat of boxes	210
How to do it	207
Large work	222
Long articles	209
Mandrels and arbors	219-220
Method of packing	206
Milling cutters	212-213
Phosphorus to be avoided	205
Possibilities of	224
Reamers	222-223
Similar articles together	208
Swaging dies	223
Tanks should be convenient	222
Taps and dies	215-221
Time necessary	211
Wiring the work	207
Wrong way of doing	208
Packing for case hardening	228

Packing gauges for hardening.....	240
Material	232
Pan of sand for drawing temper.....	118
Partial heating.....	127
Paste for coating small tools	98
Covering work	46
Peculiarities of tool steel.....	22
Percentage of carbon	15-20-21-29-33
Carbons for tools.....	284
Penetration of carbon in iron.....	275
Phosphorus affects steel.....	272-283
Bad effects of.....	83
Makes steel brittle	252
Piercing punch	141
Pinion gear—hardening of	237
Pipe cutters	288
Machine jaws.....	292
Pipes in steel bars.....	32
Planer tools	293-294
Plates—cooling	179
Pliability of hardened steel.....	66
Pliers for cutting.....	291
“Points” of carbon.....	21
Poisonous fumes	47-52-53
Potash	261
Preventing decarbonization locally	46
Dross forming on top.....	101
Lead sticking to work.....	98-103
Local hardening.....	249-250
Springs in ring gauges.....	195
Prevention of cracking.....	138-139
Springing of long articles.....	30
Process of annealing in boxes	77
Production—cheapening cost of.....	8
Increase in	10
Prussiate of potash for case hardening.....	226
Punch—buckling of	141
Blacksmiths.....	294
Blanking work.....	294
Drawing temper of	142-143
Hardening of.....	141
Heating machine for	143

Punch for hot trimming.....	294
Sheet steel	141
Track work	295
Punch or die hardest?	140
Punch press dies.....	138-143-241-289
Quality and carbon.....	22
Quantity of work to be case hardened	226
Rapid heating.....	60-61-298
Raw bone contains phosphorus	252
Razor temper.....	20
Reamer—heating a long	128
Reamers	158-162-222-223-295
Dull cutters may spoil	303-304
Half round	162-163
Heating in lead bath	104
Reasons for temper colors.....	124-125
Using lead bath.....	100
Reducing worn dies	197
Refining—heat	13-56-60
By hammering.....	69-70
Temperature	13-56-60
Reheating to draw temper.....	116
Remove strains	65-66-67
Reliable steel.....	282
Removing lead from steel.....	102
Strains from grooved rolls.....	194
Rendered beef suet.....	261
Resin	261
Use of—caution	104-105
Restoring burnt steel.....	298
Results of case hardening.....	237
Revolving furnace for drawing temper.....	118-119
Ring dies.....	144
Drawing temper.....	147-148
Furnace for	145
Hardening	144-145-147
Ring gauges—hardening of.....	195-196
Rings without welds	311-312
Rising heat.....	62
Rock drills	290

Rotting of steel	88
Roughing out work	24-25
Safety valve springs	269
Sal ammoniac for case hardening	226
Salt and cyanide bath	53-105
Salt for case hardening	226
Satisfactory annealing	75-76
Saturated solution	86
Saw arbors	286
Saw-file temper	21
Saws for wood	295
Hardening of	179
Steel	295
Tempering	183
Scale formed in dies—removing	134
Scrapers	295
Screw cutting dies	289
Hardening	149
Method of heating	152
Preventing twist	150
Screw-drivers	183-186-295
Screws—case hardening	238
Screw threading dies	148-229
Seasoning of gauges	196
"Second blue"	268
Self-hardening steel	278
Annealing	281
Separating steel	33
Set temper	21
Shafts for high speed	295
Shank mill—cooling	94
Shank mills—hardening	169-170
Methods of making	170
With holes	171
Shapes of steel bars	28
Sharp corners to be avoided	178
Shear steel	276
Sheet steel—annealing	270
Springs	270
Shifting the blame	80
Singing of steel in bath	90

Slender articles—hardening	258
Slender tools	273
Slitting saws—drawing temper	183
Slotting saws—hardening of	176
Slow heating	60-61-299
Best for tempering	125
Small bath for cooling	94-95
Lots of case hardening	226
Pieces—method of case hardening	229
Taps, reamers, etc.	158
Work—heating in tubes	41-42
Snap gauges	215-216-240
"Soaking"	299
Soft places on work	249-250
Portions—leaving	248
Soap	261
Spots where lead sticks to steel	102
Special preparations	232
Steels	275
Spermaceti oil	261
Sperm oil for springs	261
Spindles	242
Spindle steel	295
Temper	21
Spirit lamp for heating	44-45
Spoiled steel	9
Spring dies	152
Springing of mandrel	304
To prevent	155
Spring of work by dull cutters	303
Springs—bath for	86-260-261
Best steel for	259
Carriage	296
Clocks	260
Colors of	269
Danger of bending cold	269
Flat stock	270
Furnace for heating	262
Locomotive	296
Safety valves	269
Sheet steel	270
Method of cooling	262

Springs—toughened by oil.....	259
Tempering	259
Watches.....	54-267
Stamps for steel	295
Steam forming in hollow articles.....	175
Prevents cooling.....	93
Steel	19
Affected by phosphorus.....	272
Air hardening	278
Alloy.....	277
Bessemer	286
Better than ever	277
Blister.....	276
Cast.....	286
Cemented.....	275
Choice of	28
Converted	275-286
Crucible	279-286
Difference in	16
Different	26
Doubts about	274
For chilled iron.....	281-282
For hard metals	277
For mandrels or arbors.....	189
For slender tools	273
For various tools.....	282-285
German.....	276
Hammer refined	70
(Machine)—tools	271-274
Machinery	20
Nature of	11
None best for all purposes.....	30
Open hearth.....	286
Pliability of	66
Saws.....	295
Self-hardening	278
Shear.....	276
Spoiled.....	9
Stamps	295
Usually all right.....	27
Tool.....	20
To use for springs	259

Steels—special	275
Stiffness—how to secure.....	252
Stirring lead bath to equalize heat.....	102-104
Stock—keeping separate	28
Stone work.....	288
Chisels for.....	288
Working tools.....	293
Stop all holes in dies with clay	138
Straightening hardened work	115
Steel.....	66-301
Work	26-30
Work that is sprung	79
Strains in grooved rolls.....	194
Internal	65-79
Internal—in dies	154
Removed by reheating.....	65-66-67
Strength depends on heat used	59-64
Study of steel.....	11-18-80
Substitute for borax	313
Successful steel working	18
Sudden heating is dangerous	140
Sulphur in lead—avoid it.....	97
Surface carbon	63
Square corners in counterbores.....	187
Supporting cutting edges.....	308
Swaging dies	223-289
Heating boxes for	224
Sweeps for moving pieces of work	258
Tallow for tempering springs	265
Tank for hardening small work	230
Reheating	66-67
Tanks for case hardening	255-256
Should be convenient.....	222
Should be large	139
Taps.....	296
Brightening for color.....	161
Furnace for heating.....	159
Hardening	156-160-204-215-214
Hardening bath for.....	157-158-160
Machine	296
Taper mandrels.....	186

Temper.....	20-21-28
Chisel	21
Milling cutters.....	213
Razor	20
Saw file	21
Set.....	21
Spindle	21
Tool.....	21
Tempers of tools	283-284
Temperature—critical	13
Colors	123-125
For drawing small dies.....	153
Grades of	20-21
Of counterbores.....	188
Of lead for hardening.....	103
Refining	13-56
Tempering	116
A screw driver.....	164
At very low heats	124
Heat necessary.....	117
In a revolving furnace	118-119
In oil	121
Is softening.....	116-126
Lathe tools	120
Milling cutters.....	167-168
Ring dies.....	147-148
Saws	183
Small dies.....	153
Spoiled steel.....	82
Springs	259-265-266
Springs by thermometer	266
Taps.....	162
To "second blue".....	268
Temporary bath for hardening.....	257
Furnace for oil	121
Tepid water for hardening.....	176
Test after hardening.....	301
Pieces.....	57-58-61
Wires in annealing	76-77
Wires when case hardening.....	227
Testing a screw driver.....	185
Bars in stock.....	32

Testing bicycle crank.....	82
Hardened work.....	82
Heat of boxes.....	210-212
Steel	33-57-58-61
Work occasionally.....	244
Thermometer—care of	266
For gauging heat.....	119-211
In spring tempering.....	266
Thin articles—hardening.....	180-244
Threading dies	148-289-292
Time for heating gauges	240
Needed for pack hardening.....	211
Timing heat of work.....	231
Tin heating baths.....	46
Tool steel.....	20
Heating of	55
Temper	21
Tools cut faster if pack hardened	204
For chilled iron.....	283
Hard work	33
Importance of cutting point.....	7
Lathes and planers.....	292-293-294
Of machine steel	241-243-271-274
Steel for.....	282-285
Stone	293
Weakened by grinding.....	308
Wood-working.....	293
Tongs for hardening mandrels or arbors	191
Hardening thin articles.....	178
Heavy dies	136
Preventing hardening.....	249-250
Toughening bath.....	87
Steel	239
Toughness—how to produce	252
In wood-working tools	200
Tubes for heating small work	41-42
Turpentine	261
Track work punches.....	295
Trimming punches.....	294
Trouble—causes of.....	297
Troubles from forging	68
T slot cutters	171-172-173-174

Twist drills.....	290
In hardening dies.....	150
Types of furnaces.....	37-38
Hollow mills.....	177
Uneven hardening from small baths..	255
Heating.....	14-26-60
Heats.....	297-302
Uniform annealing heat necessary ..	84
Heating.....	14-26-60
Heats the secret of success.....	112
Temperature necessary.....	264
Valuable men to have	128
Vent holes in hollow mills.....	176-177
Vine-like effect in coloring	109
Warm water for hardening	176
Waste through improper handling	9
Watch spring hardening.....	54-267
Water annealing	73
Bath.....	86
Cooled oil bath.....	214
May crack work	306
Welding	310
Heat for	310
Rings—how to avoid.....	311-312
Steel—don't	311
Wine suppers and steel'	87
Wire pullers	292
Wires for testing heat.....	76-77
Wiring pieces to be hardened.....	207
Wood saws.....	295
Chisels	287
Tools	199-200-201-293
Working augers	287
Work done depends largely on tools.....	7
Of tool depends on heat used	126
Workman	15
Wrong annealing.....	82
To anneal.....	81
Way of pack hardening.....	208
Wrought iron—case hardening	225

Index to Matter added to Fourth Revised Edition including High Speed Steels.

Annealing high-speed steel.....	325
Ball-bearings	363, 364
Baths for tempering.....	349, 350
Bluing and browning steel.....	361, 362, 363
Carbon-influence of.....	320
Carborundum wheels.....	356, 357
Case hardening locally.....	365
Chromium	321
Clearance of tools.....	323
Cold-shortness	359
Colors for tempering.....	349, 351
Cracks and flaws.....	366
Critical range	340
Cutting speed	318-337
Drawing temper	336
Drilling hard steel.....	367
Electric furnaces	354
Electrical heat for hardening.....	332
Electrical ovens	352, 353
Emery wheels	356, 357
Etching steel	367
Feeds	337
Finishing	360
Forging	328-331
Frosting steel	367
Gledhills tests	320
Grinding	355, 356, 357
Hardening	332-346
Hardening rock drills.....	338
Hardening wire	366
Hardening without scale.....	366
Hardenite	341, 342
Heat for forging.....	324-331

High-carbon steels	340, 343
High-speed steel	317
High-speed tool steel.....	324, 357, 358, 359
Instruction for high-speed steels.....	330
Low-tungsten steel	343
Magnet gauges	342, 343
Magnetic properties	343
Martensite	341, 346
Misleading tests	318
Molybdenum	322
Novo steel	357, 358, 359
Pearlite	341, 342
Point of recalescence.....	340, 341
Polybdenum	322
Pyrometers	354, 355
Quenching	340, 341
Quenching baths	347
Recalescence	340, 341, 344, 345
Red-shortness	359
Restoring burnt steel.....	366
Rock-drills hardening and tempering.....	338
Salt baths	352, 353
Shapes of high-speed tools.....	324
Shop hints	365, 366
Silicon	323
Special treatments	365
Speed of work	318-337
Steel for gas engines.....	365
Steels, high-speed	317
Temperatures	348
Temperature changes	344, 345
Tempering	336
Tempering carbon-steel	349
Tempering rock-drills	338
Tests that mislead.....	318
Tools for high-speed work.....	323-324
Tungsten steel	322, 340

DIRECTORY OF SUPPLIES.

AIR HARDENING STEEL.	
Edwin R. Kent & Co.....	Chicago, Ill.
Geo. R. Nash & Co.....	New York.
Edgar T. Ward's Sons.....	Boston, Mass.
BORING TOOLS.	
Three Rivers Tool Co.....	Three Rivers, Mich.
CASE HARDENING FURNACES.	
American Gas Furnace Co.....	New York.
Chicago Flexible Shaft Co.....	Chicago, Ill.
COUNTERBORES.	
R. M. Clough.....	Tolland, Conn.
DRAWN STEEL SHAPES.	
Kidd Bros. & Burger Steel Wire Co.....	Aliquippa, Pa.
DRILL CHUCKS.	
Edwin R. Kent & Co.....	Chicago, Ill.
DRILLS—CORE.	
Three Rivers Tool Co.....	Three Rivers, Mich.
DRILLS—DEEP HOLE.	
Three Rivers Tool Co.....	Three Rivers, Mich.
DRILL RODS.	
Edwin R. Kent & Co.....	Chicago, Ill.
Patriarche & Bell.....	New York.
Kidd Bros. & Burger Steel Wire Co.....	Aliquippa, Pa.
DRILLS—TWIST.	
Edwin R. Kent & Co.....	Chicago, Ill.
EMERY WHEEL DRESSERS.	
Geo. H. Calder.....	Lancaster, Pa.
FORGES—GAS.	
American Gas Furnace Co.....	New York.
FURNACES—GAS.	
American Gas Furnace Co.....	New York.
Chicago Flexible Shaft Co.....	Chicago, Ill.
FURNACES—OIL.	
Chicago Flexible Shaft Co.....	Chicago, Ill.
FURNACES—OIL—AUTOMATIC.	
American Gas Furnace Co.....	New York.
GRINDERS—CUTTER.	
R. M. Clough.....	Tolland, Conn.